

Aspire

Super Display Quick Reference

Using the Super Display Features

The Aspire Super Display telephone provides the ability to display either a calendar or One-Touch keys which the user can personally program to best suit their needs.

Using the Calendar

If the Calendar is not displayed, press the “Cal.” soft key. This key changes from “OneT” to “Cal.” depending on the view currently active on the Super Display telephone.


When the Super Display phone is plugged in, the system sets the display in the calendar mode, with the current week displayed on the top row of the display.

To scroll the calendar ahead, week by week, press the Soft Key 1 (top left). Pressing Soft Key 6 (top right) scrolls the calendar weeks back.

To change the display back to the current week, press the Clear key.

Press to scroll
the weeks
ahead.

Press to scroll
the weeks
back.



Press to switch
to display the
One-Touch keys.

Press to switch the display
to the current week.

